





Service Call: +86-13711988687



The fully automatic micro hardness tester is mainly used for measuring small and thin test pieces and brittle hardware. It can be widely used in various metals (ferrous metals, non-ferrous metals, castings, alloy materials) by selecting various accessories or upgrading various structures. Etc.), metal structure, metal surface processing layer, electroplated layer, hardened layer (oxidation, various infiltration layers, coating), heat-treated test piece, carbonized test piece, quenched test piece, minute part of phase inclusion, glass, agate Testing of brittle and hard non-metallic materials such as artificial gemstones and ceramics. It is especially suitable for measuring the hardness gradient profile of workpieces in large quantities and the hardness test of specified parts.

The automatic stage controlled by the built-in stepping motor has a variety of control modes through mouse click control, high positioning accuracy, good repeatability, fast moving speed and high work efficiency;

### Hardness tester technical parameters

Parameters name	Parameters data			
Micro hardness scale	HV0.01,HV0.025,HV0.05,HV0.1,HV0.2,HV0.3,HV0.5,HV1			
monitor	7寸 LCD monitor			
Test force (gf)	10, 25, 50, 100, 200, 300, 500, 1000			
Load control	Automatic (load/hold/unload )			
Test force retention	5∼60			
time(s)				
Test foce selection	External force selection knob, the test force is automatically			
	displayed on the 7-inch LCD touch display			
Objective magnification	10×, 40×			
Optical channel	Double optical channel (eyepiece and CCD camera channel)			
Optical system (dual	1. Automatic digital encoder;			
optical channel, no need	2, the total magnification ( $\mu$ m): 100 × (observation), 400 ×			
to switch)	(measurement);			
	3. Measurement range (µm): 200; 4, resolution (µm): 0.01			
Hardness measurement	(5-3000)HV			
range				
Data output (optional)	Built-in printer, test data can also be saved to USB flash drive for			
	storage analysis			
Maximum height of the	90			
test piece(mm)				
Maximum width of test	120 indenter center line to machine wall distance)			
piece(mm)				
voltage	AC220V/50HZ			
Weight(kg) 40				

Service Call: +86-13711988687




#### Parameters software:

#### 1 instruction

Fully automatic micro Vickers hardness tester integrates various latest professional technologies such as optical imaging, mechanical displacement, electronic control, digital imaging, image analysis, computer processing, etc., and realizes Vickers hardness tester and automatic stage through computer mainframe. Control, and digitally image the hardness indentation on the computer screen, and then accurately measure the microhardness of the metal and some non-metallic materials and various layers and coatings, the depth of the hardened layer, and the film layer by means of automatic reading and manual reading. Thickness, two-point spacing, etc. It is also possible to take a picture of the metal surface and print it at a fixed rate. This system breaks through the traditional hardness test method and realizes the automatic, high-precision and high-repetition hardness test, which is an important equipment for material analysis.

### 2 composition

The computer host controls the operation of the hardness tester through the RS232 serial port and receives the corresponding information of the hardness tester; the host computer controls the platform control box through the RS232 serial port, and controls the automatic stage to move and receive corresponding information through the platform control box; Vickers hardness The opticalVickers hardness value is measured by automatic and manual signal of the pressed indentation is imaged on a computer display by a digital camera, and the Vickers hardness value is measured by automatic and manual reading.




Service Call: +86-13711988687




## 3. The main function:

materials	instructions
Pressure control	When the hardness tester is switched, the system senses the change in the
	test force and displays it in the system in real time.
Turret control	Software controlled hardness tester to switch between objective lens and
	indenter without manual control of hardness tester
Load control	The software controls the hardness tester for loading without the need for
	manual control of the hardness tester.
Measurement	Software control hardness tester turret, load and directly read Vickers hardness
control	values
Z axis control	Software controlled hardness tester Z axis rise and fall
Auto focus	The software controls the Z-axis autofocus of the hardness tester to find the sharpest
control	point on the surface of the product.
Light source	Set the brightness of the light source
brightness	
control	
graphic	Display hardness images in real time, store and print images, and print multiple
gathering	times.
Manual /	Manual: Pull diagonal measurement, two-point card line measurement,
automatic	four-point measurement, automatic: automatically find the four vertices of
measurement	the indentation, the speed is fast, the data is accurate. Even hit the test, that
	is, hit the test, specify the coordinates to suppress.
Hardness	Automatically perform various hardness value conversions such as
conversion	Brinell-Louis-Vickers-Knoop in accordance with national standards, real-time display,
	and can convert various international standards.
Graphic report	Automatically record measurement data, automatically generate hardness-depth
	curves, save or print hardness-depth curves and all indentation measurements; save
	or print indentation images and current indentation hardness values;
	The inspection report can be customized according to user requirements; through
	the data processing software, the depth value of the hardened layer formed after
	continuous measurement of the sample can be displayed in tabular form; various
	measurement data can be output, D1, D2, hardness value table, hardened layer
	depth, Maximum, average, minimum, display and output each indentation picture.
	Hardness value, hardness table, hardened layer depth map and image insertion data
	can be flexibly edited in WORD or EXCEL to print test reports containing
	mathematical statistics and hardened layer depth curves and save WORD format or
	EXCEL, and also print the observed samples. The topography is saved and directly
	reflects the microstructure of the indentation and background.
Knoop	Replaceable Knoop indenter for automatic measurement of Knoop hardness
measurement	





Automatic Z axis	Auto focus step (m): Move the step when the Z axis is automatically adjusted, the default is 1.25m.						
	Z-axis button step (m): Keyboard or interface direction button button Z						
	7 avis rise and falls	moving distance, default 1.25m					
		Z-axis rise and fall: low speed (mm/s): default 0.0625mm/s. high speed					
	(mm/s): default 1.0mm/s. adjustable speed。						
Automatic	You can automatically select points at any point in the interface by clicking						
loading platform	the mouse. You can set the starting position of the line and the random moving position. You can control the speed of the automatic XY stage in any						
		mouse to control the mover	_				
	•	and the coordinates can be					
	The software system p	rogrammable control of the	automatic stage				
	movement, the system	n provides 14 modes:					
	1) Along the line;	2) Angle along the line;	<ol><li>Free click;</li></ol>				
	4) Lateral along the line	; 5) Longitudinal;	6) Multiple lines along the				
		curve;					
	7) Along the curve matri	x; 8)Arc; 9)	Tooth heart;				
	10) Paragraph parallel;	11) Automatically angled al	ong the edge; 12) Automatic				
		edge matrix;					
	13) Center of mind;	14) Parallel along the cur	ve				
	motor	Steppe	er motor				
	Maximum moving	50	mm				
	distance						
	Minimum moving	1	um				
	distance						
	Moving speed	Adju	stable				
	Displacement repeat	1	um				
	accuracy						
	Sample stage size	100mm	X100mm				
Image acquisition	High-quality, high-resolu	solution 3 megapixel camera, high-speed acquisition: 1280X102					
/recognition	resolution: 25 frames / sec, large-size original image acquisition; image and						
	measurement results for	or storage format, image storag	ge format BMP, JPG and other				
		common file formats					
Automatic		About 0.3S/1 indentation	1				
measurement							
time							
Measurement	±1.0% (	700HV/500gf,When the inde	entation is clear )				
repeatability	,	, 0					
Minimum unit of		0.01μm					
measure		5.01μ					





# The standard configuration

Micro hardness	10g-1kg test force;							
	The test force convertible unit is: (Kgf, N);							
tester	The optical system designed by senior optical engineers not only has clear images, but also can be used as a simple microscope. The brightness is adjustable, the vision							
	is comfortable, and it is not easy to fatigue when working for a long time;							
	The 7-inch LCD touch can visually display the hardness value, conversion hardness,							
	test method, test for	test method, test force, load-keeping time, number of measurements, and the test						
	process is straightfor	rward;						
	The system comes w	ith a ca	libration function that ca	an mai	nually adjust the inpu	t		
	error calibration instrument; The upper and lower limit measurement ranges can be set and displayed on the main							
	measurement interf							
	Loading method: fully automatic;							
		Lens and indenter conversion: fully automatic;						
	The coincidence accuracy of the objective lens and the indenter center is less than 1					nan 1		
	um;	hall is f	formed once the structu	ro ic ct	able and not deform	a d		
			ormed once, the structu s high grade and strong s			eu,		
	· ·		isly converted to Rockwe					
	The results are simu	itaneou	isily converted to Nockwe	ii, vicr	ers, brillell,			
The standard	Microscopic	1	10X objective	1	40X objective	1		
configuration:	Vickers indenter	_		_		_		
comiguration.	Vickers indenter							
	\Maight	-	Weight rod	1	10v micromotor	1		
	Weight	6	Weight rod	1	10× micrometer	1		
					eyepiece			
	24: 15:1							
	Micro Vickers	2	Electric cross	1	Sheet holding	1		
	hardness block		workbench		table			
	Flat mouth	1	Filament clamping	1	Level	1		
	clamping table		table					
	Leveling screw	4	Screwdriver	2	External power	1		
					cord			
	Dust cover	1	Installation and	1	Optical adapter	1		
	Dust cover	-	operation manual	_	Optical adapter	-		
	LICD Danala		·	1	Coftware dies	1		
	USB Dongle	1	camera	1	Software disc	1		
	Control dedicated	1	RS232Communicatio	1	Electric platform	1		
	cable		n line		controller			
Software setting:								
XY sample	Provide XY electric moving sample stage: can be controlled by software or manually;							
movement	XY can move at the same time; XY can be fine-tuned with the keyboard direction keys							
control	precisely;							
		Cont	rol VV Floatric Marriage Ca	mala	Stago			
XYZ remote		Cont	rol XY Electric Moving Sa	inpie :	otage			
sensing								



Load mode and path settings	Provide a variety of loading modes including along the line, along the edge angle, along the edge of the curve, etc.; loading point coordinates can be arbitrarily set			
Automatic edge scan	Automatically scan along the edge of the sample and automatically find inflection points such as crest roots, etc.			
Auto load, focus,	The system presses the set loading mode, auto focus, auto load, automatic			
measurement	measurement, and automatically draws the hardening curve; one button to complete			
Hardness value	The system can simultaneously convert the measured micro Vickers hardness value			
conversion,	to other hardness scales such as HB, HR, etc.; the spherical cylindrical sample			
correction, valid	measurement value can be corrected; the sample measurement value can be			
verification	effectively verified			
Data statistics	Automatic calculation of the average value, variance, Cp, Cpk and other statistical			
	values of measured hardness			
Data storage	Measurement data and images can be saved in a document for later recall			
testing report	Automatically generate WORD or EXCEL document reports; user-customizable report			
	formats; standard formats include each individual hardness measurement, statistical			
	value, indentation image, and hardening curve			
Knoop hardness	Can be set to measure Knoop hardness			
Fracture toughness	Can be set to measure indentation fracture toughness			
Otherfunctions	Includes all the functions of a microscopic image processing and measurement			
- Strict falletions	system, including image capture, calibration, image processing, geometry			
	measurement, document annotation, photo album management, and fixed-line			
	printing.			
computer	Lenovo business computer			
computer	Lenovo business computer			